

Transferring Oberaufsichtlicher Wob.
 anwendbar, wobei alle Tugenden in
 Leipziger Fußbauung abum.
 dabei sind Tugenden an.

XVII 300
 XVII 300148 (196)

$n. ang. = 75^\circ$ $n. ang. = 45^\circ$ $n. ang. = 22\frac{1}{2}$
 $A = 1\frac{1}{3} f.$ $r. = \frac{1}{6} f.$ $W. = 1 f.$

0.4971499	3.14159	= π
0.9942998		= π^2
1.2375437		= $\frac{1}{2}\pi^2$
9.7567561		= $\frac{\pi^2}{9}$
9.5828397	0.3826834	= $\sin n.$
9.9656153	0.9238795	= $\cos n.$
0.2218488	1.66666	= A
0.4436975	2.77777	= A^2
9.8046885	0.6378057	= $A \cdot \sin n.$
0.1874641	1.5397992	= $A \cdot \cos n.$
	0.833333	= $r.$
	0.694444	= r^2

Pro $A = 1.5$

0.1760913	1.5	= A
0.3521826	2.25	= A^2
9.7589310	0.5740257	= $A \cdot \sin n.$
0.1417066	1.2858192	= $A \cdot \cos n.$