

Figure	Defect	Cause
--------	--------	-------




Fig. 285 A

Normal wear and tear




Fig. 285 B

Tread worn out

Insufficient inflation pressure




Fig. 285 C

Wear due to grinding action of tyres

Careless driving of the tractorist